




**BARKER AND
STONEHOUSE**

Jasper Dining Chair
Assembly instructions










Parts checklist

Please check you have all the parts listed below with your product.

| | | |
|--|--|--|
| <div>1</div>  | <div>2</div>  | <div>3</div>  |
| Seat | Leg | Leg |
| 1pc | 1pc | 1pc |


Fittings checklist

Please check you have all the fittings listed below with your product.

| | | | |
|--|--|---|--|
| <div>4</div>  | <div>5</div>  | <div>6</div>  | <div>7</div>  |
| Bracket | Swivel Mechanism | M6x30mm Bolt | M6x16mm Bolt |
| 1pc | 4pc | 9pc | 2pc |
| <div>8</div>  | <div>9</div>  | <div>10</div>  | |
| M6x25mm Bolt | Washer | Allen Key | |
| 2pc | 2pc | 1pc | |


Step 1

Attach legs (2&3) to the bracket (4) as below, using 4x bolts (6).



Step 2

Sit the swivel mechanism (5) diagonally on top of the bracket (4) and secure it with 4x bolts (6).



Step 3

Position the seat (1) upside down and attach the base using bolts (7&8) and washers (9).

